



Description

The Patient Check Pad (I126) is used with an IRU with Patient Check (I595.8), an Incilog Incilog Comms with Incilog Software and Patient Call Check (I352.9) and a Badge Pit with Wireless Call Reset (I216.6/I216.7).

The Patient Check Pad should be installed at an appropriate height and place for its intended use so that it is easily accessible, for example beside the patient's bed. Using the wireless feature on their Badge Pit, staff should touch it against the image in the centre of the Patient Check Pad to confirm they have checked on the patient at regular intervals - every 15 minutes is recommended. The unit features a reassurance LED which will illuminate when the Badge Pit has successfully activated the Check Pad. This will then be logged accordingly by the Incilog Software showing when the patient has been checked on and where.

Additionally, the unit features a white single gang fascia manufactured from a Polycarb/ABS blend for maximum durability in harsh environments.

Model No:	I126
Power Source:	12V to 13.8V DC
Size:	Height 4.5" x Width 2.76" x Depth 0.83"
Weight:	1.76oz (50g)
Backbox:	US Single Gang
Screws:	6-32 UNC countersunk screws
Antimicrobial:	Yes